

## **Instructions for Key Reprogramming Volkswagen Routan 2009 and newer**

1. Connect a battery charger to the vehicle.
2. Connect the StarMobile scan tool.
3. Have a unique vehicle PIN readily available before running the routine. The PIN can be obtained from the owner of the vehicle or from a Volkswagen dealer.
4. Ignition key should be in RUN position.
5. Select "ECU View".
6. Select "WIN Wireless Control".
7. Select "Miscellaneous Functions."
8. Select "Program Ignition Keys or Key FOBs", Start
9. Enter the PIN when prompted.
10. Verify the correct information.
11. Cycle ignition key after the successful routine completion.