

Instructions Specifically Developed for Dealer Technicians

Description: Passat 18" Wheel Suspension Limiter

Part Number: 000 071 501 Suspension Limiter Kit

Quantity: 2 Front, 2 Rear

Supplier: Votex GmbH

Publish Date: 29 July 2005

29 July 2005

AG. Volkswagen AG. Volkswagen AG. does not guarantee or account guarante



Attention:

Before starting, make sure painted and trim surfaces are protected to avoid scratching during installation process of the items. Use proper surface protection covers and work attire free of dirt and grease



\ Caution:

Read entire instructions thoroughly before starting. Installation should be performed only by a qualified person. Observe all safety precautions when working beneath a vehicle. Beware of sharp edges. Always wear safety glasses for eye protection.

© 2005 Volkswagen of America, Inc. All rights reserved. Information contained in this document is based of the latest information available at the time of printing and is subject to the copyright and other intellectual property rights of Volkswagen of America, Inc., its affiliated companies and its licensors. All rights are reserved to make changes as any time without notice. No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopy, recording or otherwise, nor may these materials be modified or reposted to other internet sites, without expressed written permission of the publisher.

1



Part Number: 000 071 50 1 gen AG. Volkswagen AG does not guarantee or actintion: Suspension Limiter

Required tools

1/2" Ratchet

1/2 Breaker bar


1/2 Torque Wrench

6" Extension

14 mm socket

19 mm socket

T1001 Special tool





Part Number: 000 071 501

Description: Suspension Limiter

Supplier: Votex GmbH

Installation Kit






Part Number: 000 071 501 Description: Suspension Limiter


Supplier: Votex GmbH



Step#01 (FRONT) Detach the bottom of the dust boot on the front strut.



Step#02 Install the suspension limiter on the strut shaft




Step#03 Install the retainer on the suspension limiter and slide to the stop at the top of the strut. Repeat for other side.





Part Number: 000 071 501 Description: Suspension Limiter

Supplier: Votex GmbH




Step#04 (REAR) Support the lower control arm and remove the lower mounting bolt from the shock absorber.



NOTE:

The wheel is removed for and easier removal and installation of the shock absorber



Step#05 Remove the upper mounting bolts 2x and remove the shock absorber



Step#06
Use special tool T1001 to
disassemble the upper mounting
of the shock absorber



Part Number: 000 071 501

Part Number: 000 07 1 00.

Description: Suspension Limiter. Volkswagen AG does not guara





Buffer, Limiter and Retainer

Upper Mount and Nut



Install the suspension limiter and reassemble the upper mounting using special tool T1001 and torque the retaining nut to 25 Nm





Limiter installed



Don't forget the retainer.



Step#08

Reinstall the shock absorber using a support at the lower control arm.

The upper mounting bolts are torque to yield bolts and must be replaced.

The upper mounting bolts are torqued to 50 Nm plus an additional 45°.

Install the lower mounting bolt and torque to 180 Nm

The rear suspension camber alignment must be changed from -1° 20" to -1° 45"



NOTE:

Part Number for upper mounting bolt: N 906 484 01

Cautions & Warnings not gualfante

Please read these WARNINGS and CAUTIONS before proceeding with maintenance and repair work. You must answer that you have read and you understand these WARNINGS and CAUTIONS before you will be allowed to view this information.

- If you lack the skills, tools and equipment, or a suitable workshop for any procedure described in this manual, we suggest you leave such repairs to an authorized Volkswagen retailer or other qualified shop. We especially urge you to consult an authorized Volkswagen retailer before beginning repairs on any vehicle that may still be covered wholly or in part by any of the extensive warranties issued by Volkswagen.
- Disconnect the battery negative terminal (ground strap) whenever you work on the fuel system or the electrical system. Do not smoke or work near heaters or other fire hazards. Keep an approved fire extinguisher handy.
- Volkswagen is constantly improving its vehicles and sometimes these changes, both in parts and specifications, are made applicable to earlier models. Therefore, part numbers listed in this manual are for reference only. Always check with your authorized Volkswagen retailer parts department for the latest information.
- Any time the battery has been disconnected on an automatic transmission vehicle, it will be necessary to reestablish Transmission Control Module (TCM) basic settings using the VAG 1551 Scan Tool (ST).
- Never work under a lifted vehicle unless it is solidly supported on stands designed for the purpose. Do not support
 a vehicle on cinder blocks, hollow tiles or other props that may crumble under continuous load. Never work under a
 vehicle that is supported solely by a jack, Never work under the vehicle while the engine is running.
- For vehicles equipped with an anti-theft radio, be sure of the correct radio activation code before disconnecting the battery or removing the radio. If the wrong code is entered when the power is restored, the radio may lock up and become inoperable, even if the correct code is used in a later attempt.
- If you are going to work under a vehicle on the ground, make sure that the ground is level. Block the wheels to keep the vehicle from rolling. Disconnect the battery negative terminal (ground strap) to prevent others from starting the vehicle while you are under it.
- Do not attempt to work on your vehicle if you do not feel well. You increase the danger of injury to yourself and
 others if you are tired, upset or have taken medicine or any other substances that may impair you or keep you from
 being fully alert.
- Never run the engine unless the work area is well ventilated. Carbon monoxide (CO) kills.
- Always observe good workshop practices. Wear goggles when you operate machine tools or work with acid. Wear
 goggles, gloves and other protective clothing whenever the job requires working with harmful substances.
- Tie long hair behind your head. Do not wear a necktie, a scarf, loose clothing, or a necklace when you work near machine tools or running engines. If your hair, clothing, or jewelry were to get caught in the machinery, severe injury could result.
- Do not re-use any fasteners that are worn or deformed in normal use. Some fasteners are designed to be used only once and are unreliable and may fail if used a second time. This includes, but is not limited to, nuts, bolts, washers, circlips and cotter pins. Always follow the recommendations in this manual replace these fasteners with new parts where indicated, and any other time it is deemed necessary by inspection.



Cautions & Warnings

- Illuminate the work area adequately but safely. Use a portable safety light for working inside or under the vehicle. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.
- Friction materials such as brake pads and clutch discs may contain asbestos fibers. Do not create dust by grinding, sanding, or by cleaning with compressed air. Avoid breathing asbestos fibers and asbestos dust. Breathing asbestos can cause serious diseases such as asbestosis or cancer, and may result in death
- Finger rings should be removed so that they cannot cause electrical shorts, get caught in running machinery, or be crushed by heavy parts.
- Before starting a job, make certain that you have all the necessary tools and parts on hand. Read all the instructions thoroughly; do not attempt shortcuts. Use tools that are appropriate to the work and use only replacement parts meeting Volkswagen specifications. Makeshift tools, parts and procedures will not make good repairs.
- Catch draining fuel, oil or brake fluid in suitable containers. Do not use empty food or beverage containers that might mislead someone into drinking from them. Store flammable fluids away from fire hazards. Wipe up spills at once, but do not store the oily rags, which can ignite and burn spontaneously.
- Use pneumatic and electric tools only to loosen threaded parts and fasteners. Never use these tools to tighten fasteners, especially on light alloy parts. Always use a torque wrench to tighten fasteners to the tightening torque Protected 6 listed.
- Keep sparks, lighted matches, and open flame away from the top of the battery. If escaping hydrogen gas is ignited, it will ignite gas trapped in the cells and cause the battery to explode.
- Be mindful of the environment and ecology. Before you drain the crankcase, find out the proper way to dispose of the oil. Do not pour oil onto the ground, down a drain, or into a stream, pond, or lake. Consult local ordinances that govern the disposal of wastes.
- The air-conditioning (A/C) system is filled with a chemical refrigerant that is hazardous. The A/C system should be serviced only by trained automotive service technicians using approved refrigerant recovery/recycling equipment, trained in related safety precautions, and familiar with regulations governing the discharging and disposal of automotive chemical refrigerants.
- Before doing any electrical welding on vehicles equipped with anti-lock brakes (ABS), disconnect the battery negative terminal (ground strap) and the ABS control module connector.
- Do not expose any part of the A/C system to high temperatures such as open flame. Excessive heat will increase system pressure and may cause the system to burst.
- When boost-charging the battery, first remove the fuses for the Engine Control Module (ECM), the Transmission Control Module (TCM), the ABS control module, and the trip computer. In cases where one or more of these components is not separately fused, disconnect the control module connector(s).
- Some of the vehicles covered by this manual are equipped with a supplemental restraint system (SRS), that automatically deploys an airbag in the event of a frontal impact. The airbag is operated by an explosive device. Handled improperly or without adequate safeguards, it can be accidentally activated and cause serious personal injury. To guard against personal injury or airbag system failure, only trained Volkswagen Service technicians should test, disassemble or service the airbag system.



- Do not quick-charge the battery (for boost starting) for longer than one minute, and do not exceed 16.5 volts at the battery with the boosting cables attached. Wait at least one minute before boosting the battery a second time.
- Never use a test light to conduct electrical tests of the airbag system. The system must only be tested by trained Volkswagen Service technicians using the VAG 1551 Scan Tool (ST) or an approved equivalent. The airbag unit must never be electrically tested while it is not installed in the vehicle.
- Some aerosol tire inflators are highly flammable. Be extremely cautious when repairing a tire that may have been inflated using an aerosol tire inflator. Keep sparks, open flame or other sources of ignition away from the tire repair area. Inflate and deflate the tire at least four times before breaking the bead from the rim. Completely remove the tire from the ring before attempting any repair.
- When driving or riding in an airbag-equipped vehicle, never hold test equipment in your hands or lap while the vehicle is in motion. Objects between you and the airbag can increase the risk of injury in an accident.

I have read and I understand these Cautions and Warnings. Ardid Billydo Arbingho Vd bolosion

ngari. Copyitanty Volkswagen AG.